

C-207

BBツール

このたびはホーザン C-207 BBツール をお買い上げいただき、まことにありがとうございます。この取扱説明書をよくお読みになり、正しくお使いください。また、お読みになったあとも大切に保管してください。


各部の名称



仕様

対象ボトムブラケット

右側	6溝タイプ/2溝タイプ
左側	2溝タイプ/ 凸タイプ(16.3mm幅)



ご使用上の注意

注意

1. 本器を改造しないでください。
2. 本器に割れ・欠け、摩耗、変形などが認められる場合は使用しないでください。

ご使用方法

本工具は自転車のネジタイプのBB(ボトムブラケット)を締め付けたり、緩めたりするためのものです。

- 1 ボトムブラケット(以下BB)の軸からクランクを取り外します。
- 2 作業する側のBB軸の先端にガイドを取り付けます。ガイドには雄ネジと雌ネジを備えていますので、BB軸先端の雌または雄に合わせてご使用ください。
- 3 本器本体をガイドを通して、BBにセットします。BBのタイプにより、合致する方の本体の面をBBに噛み合わせてください。
- 4 32mmのレンチを本器にあてがい、BBから本器が外れないように手で押さえつけながら回転させます。

POINT

ネジの方向にご注意ください。
右側(ドライブトレイン側): 逆ネジ
左側 : 正ネジ

警告

必ずガイドを使用してください。本体のみでは噛み合いが確実でなく、思わぬ事故につながります。

技術的なお問い合わせ

ホーザン テクニカルホットライン

☎06-6567-3132 E-mail: th@hozan.co.jp
【月曜日から金曜日(祝日を除く)の10:30~12:00・13:00~17:00】

※修理部品については、web上のパーツ内容をご覧ください。
通信販売もご利用いただけます。【ホーザン 誠実販売】

ホーザン株式会社

本社 〒556-0021 大阪府浪速区幸町1-2-12
TEL(06)6567-3111 FAX(06)6562-0024

16.04

HOZAN INSTRUCTION MANUAL


C-207

BB TOOL

Thank you for purchasing the HOZAN C-207 BB TOOL. With proper care and handling, this fine instrument will provide years of trouble-free operation. Please read this entire instruction manual carefully before attempting to place this instrument in service. Please keep this instruction manual available for reference.

Identification of parts


Main body



Specifications

Applicable BB types

Drive side	6 notched type/ 2 notched type
Non-drive side	2 notched type/ 2 protruded type with 16.3mm width



Precautions

Caution

1. Do not modify the C-207.
2. Do not use when cracks, breaks, excessive wear, or deformation is found on this tool.

Operation

This tool is for tightening and loosening screwed bottom brackets of bicycles.

- 1 Remove the crank from the axis of the bottom bracket.
- 2 Attach the guide to the top of the bottom bracket axis. The guide has both the male and female screws. Select the proper screw according to the bottom bracket to be worked.
- 3 Set the C-207 main body on the bottom bracket through the guide. Select the suitable face of the main body so that it engages with the BB.
- 4 Apply a 32 mm wrench to the C-207, then turn the wrench while depressing the C-207 not to be separated from the bottom bracket.

THE POINT

The screw's winding direction
Drive side: LH
Non-drive side: RH

Warning

Always use the guide. If operate without the guide, engaging becomes insufficient causing an unexpected accident.

HOZAN TOOL INDUSTRIAL CO.,LTD.

1-2-12 Saiwaicho, Naniwa-ku, Osaka 556-0021, Japan
Tel: +81-6-6567-3111 Fax: +81-6-6562-0024

16.04